



## UNTERMINATED VEHICLE WIRELESS PTT WIRING INSTRUCTIONS

---

---

**BLUE = GROUND**

**YELLOW = PTT**

**NOTE:** Manual PTT pulls down fully to ground but Wireless PTT will only pull PTT down 150 ohms to ground.

**RED = MIC** (Install an in line resistor to set required mic level)

**WHITE = VOLTAGE SUPPLY** (REMEMBER RESISTOR)

**NOTE:** A resistor may be required in the voltage supply line. Please see below for resistor value.

10-15 volt supply = 200 OHM resistor in series with voltage supply line.

8 volt supply = 150 Ohm resistor in series with voltage supply line.

5 volt supply = No resistor required.