













# Connector Chart









Connector Code	Connector Figure	Description	Radio Models	
GME		<b>GME/Uniden</b> Two-Pin Right Angle 3.5mmStereo+2.5mmStereo	<b>GME</b>	TX6100, TX6200, TX7200, TX630, TX670, TX680, TX655, TX665, TX667, TX675, TX677, TX685, TX6150, TX6155, TX6160
			<b>Uniden</b>	UH820S, UH850S, UH950S
H4		<b>Hytera</b> Multiple Pin	PD-702, PD-782	
H5		<b>Hytera</b> Multiple Pin	PD-600 Series, X1e, X1p	
H6		<b>Hytera</b> Single Pin	PD-372	
H1S		<b>Hytera/HYT with screw</b>	TC700, TC610, TC620, PD400 Series, PD500 Series	
HR		<b>Six-Pin Hirose</b>	Motorola Hirose wiring	

K1		Kenwood Two-Pin Right Angle 3.5mmStereo+2.5mmMono	Kenwood	TK-250/350, 260/360, 260G/360G, 270/370, 270G/370G, TK-2160/3160, TK-2170/3170, TK-3130(ProTalk XLS), 3131(Free Talk XLS), TK-2207/3207, TK-3212, TK-2202/3202, TK-2107, TK-3107, TK-2307/3307, TK-2317/3317, TK-2407/3407, TK-3310, TK-2360/3360, TK-3710X(ProTalk CB), TK-D240/D340, NX220/320, NX-240/340, NX-1000
			HYT/Hytera	HYT TC-368
			Baofeng	BF-F8+, BF-F9, UV-5R, UV-B6, UV-82
			FDC	FD-268A/B, FD-278, FD-289, FD-6288
			Puxing	PX-666, PX-777, PX-777 Plus, PX-328, PX-888, PX-888K, PX-999
			Wouxun	KG-UV6D, KG-UV6D PRO, KG-UV8D, KG-UV8D Plus, KG-UV9D, KG-UV9D Plus, KG-659, KG-669, KG-669 Plus, KG-679, KG-679 Plus, KG-689, KG-689 Plus, KG-699E, KG-UV899, KG-UVD1P
			Kirisun	PT3600
			TooAir	TA-388
			TYT	MD-380
QCOM	PD-28			
K2		Kenwood Multiple-Pin	TK-280/380, TK-290/390, TK-385, TK-480, TK-481, TK-2041, TK-2140/3140, TK-3148, TK-2180/3180, NX-200/300, NX-3200/3300, NX-5200/5300	
K4		Kenwood Single-Pin	PKT-23	
KR4		Kirisun Single-Pin	W-60	

M1		<b>Motorola</b> Two-Pin Right Angle 3.5mmMono+2.5mmMono	<b>Motorola</b>	GP68, GP88, GP300, GP308, GP350, P040, P080, P110, P1225, P1225LS, P2000, CP88, CP125, CP150, CP200, CT150, CT250, CT450, CT450LS, CP476, PRO2150, PRO3150, BPR40, EP450, MTH500, GTX, SP50, LTS2000, PR400,
			<b>HYT</b>	HYT2100, TC500, TC600, TC1600, TC2100, TC446, TC518 TC700, TC610, TC620
			<b>Midland</b>	G15, G18
			<b>Kirisun</b>	DP405, PT6500
M3		<b>Motorola</b> One-Pin 3.5mm Screwed Stereo	Visar Series	
M4		<b>Motorola</b> Multiple-Pin	ATS2500, HT750, HT1250, HT1250LS, HT1550, HT1550XLS, MTX850, MTX850LS, MTX900, MTX950, MTX960, MTX8250, MTX8250LS, MTX9250 PRO5150, PRO5350, PRO5450, PRO5550, PRO5750, PRO7150, PRO7350, PRO7450, PRO7550, PRO7750, PRO9150, PTX780 GP140, GP320, GP328, GP329, GP330, GP338, GP339, GP340, GP360, GP380, GP600, GP640, GP650, GP680, GP1280	
M5		<b>Motorola</b> Multiple-Pin	<b>Motorola</b>	EX500, EX600, GL2000, GP328plus, GP338plus, GP628Plus PTX760Plus, GP344, GP388, PRO5150Elite
			<b>RELM</b>	RPV3000, 3600/RPU3000, 3600
			<b>HYT</b>	TC380M/370M, TC780M, TC-780, TC3000
			<b>Simoco</b>	SRP9170/9180, SDP650, SDP660
			<b>Kirisun</b>	PT7200

M6		<b>Motorola</b> Multiple-Pin	<b>Motorola</b>	GP900, GP9000, HT1000, JT1000, MT2000, MTS2000, MT6000, MTX838, MTX900, MTX900, MTX1000, MTX8000, MTX9000, MTX-LS, XTS2000, XTS2500, XTS3000, XTS3500, XTS5000/5100/7700
			<b>EF Johnson</b>	5100/5700 Series, 511X, 512X, 518X
M7		<b>Motorola</b> Multiple-Pin	MOTOTRBO APX2000, APX3000, APX6000, APX7000, MTP6550 XPR6300/6500/6350/6550 DP3400, DP3600, DP3401, DP3601 DP4400/4400e, DP4401/4401e, DP4600, DP4601/4601e, DP4800e, DP4801/4801e	
M10		<b>Motorola</b> Single-Pin	Motorola CLP	
M11		<b>Motorola</b>	SL1600, SL2600, SL4010	
M12		<b>Motorola</b> Multiple-Pin	DP2000, DP2400/2400e, DP2600/2600e, DP3440/3441, DP3441e, DP3661e, XPR3300, XPR3500, MTP3100, MTP3250, MTP3500, MTP3550	
MT1B		<b>Motorola</b>	MTP850	
MC4		<b>Harris</b>	XL200P	

NK1		<b>Cassidian</b>	THR9i
S2		<b>Icom</b> Two-Pin Right Angle 3.5mmMono+2.5mmMono	IC-F3G, IC-F3GS, IC-G3GT, IC-F4G, IC-F4GS, IC-F4GT, IC-F43GS, IC-F43GT, IC-F43TR, IC-F11, IC-F11S, IC-F21, IC-F21S, IC-F31
S2Air		<b>Icom</b> Two-Pin Right Angle 3.5mmMono+2.5mmMono	IC-A6, IC-A24, IC-A15
S3W		<b>Icom</b> Two-Pin Right Angle 3.5mmMono+2.5mmStereo with Two Screws	IC-F3G, IC-F3GS, IC-F4G, IC-F4GS, IC-F11 IC-F21, IC-F31, IC-F33, IC-F43, IC-F14, IC-F24, IC-F3023, IC-F4023, IC-41S, IC-41W, IC-F3003/4003, IC-F3103D/4103D, IC-41PRO, IC-F1000, IC-F2000, IC-F3033S/4033S
S4		<b>Icom</b> Multiple-Pin	IC-F50, IC-F51, IC-F60, IC-F61 IC-F30G, IC-F30GT, IC-F30GS, IC-F31GS, IC-F31GT, IC-36FI IC-F40G, IC-F40GS, IC-F40GT, IC-35FI M87/88, IC-F3063, IC-F4063, IC-F3163, IC-F4163, IC-F3163D/4163D
S6		<b>Icom</b> Multiple-Pin Waterproof	IC-F4263, IC-F52D, IC-F62D, IC-F3400D, IC-F4400D
S8		<b>Icom</b> Two-Pin Right Angle 3.5mmStereo+2.5mmStereo	IP100, IP501
STP		<b>Sepura</b> Multipin connector with screw	STP8000, STP9000, STB8000 Series Radios

T1		<b>TAIT</b>	TP3000, TP8110, TP8115, TP8120, TP8135, TP8140, TP7110, TP9300, TP9400	
Y3		<b>Yaesu/Vertex</b> One-Pin Right Angle 3.5mm Quad with Two Screws	VX-160, VX-180, VX-210, VX-210A, VX-231, VX-351, VX-410, VX-420, VX-426, VX-451, VX-454, VX-456, VX-459, EXV-261, EVX-531, EXV534, EXV539	
Y4		<b>Yaesu/Vertex/Motorola</b> Single Pin 3.5mm Quad	EVX-S24	
Y6		<b>Yaesu/Vertex</b> Multiple-Pin	VX-820, VX821, VX824, VX829, VX920, VX921, VX924, VX929, VXD-720,	
J2		2.5mm Mono Right Angle	Any radio or remote microphone with a 2.5mm earphone jack. Except those using M2 and M2S.	
J4		<b>Uniden</b> 2.5mm Stereo Right Angle	<b>Uniden</b>	Uniden single pin 2.5mm right angle connection.
			<b>Garmin</b>	Garmin Rino 650 GPS/UHF
J6		3.5mm Mono Right Angle	Any radio or remote microphone with a 3.5mm earphone jack	
J8		3.5mm Stereo Right Angle	Any radio or remote microphone with a 3.5mm earphone jack	